


How you fit your MYSTERY RANCH Fire pack:




STEP 1: Find a friend! Loosen shoulder straps. Situate waist belt comfortably on hips and tighten.



STEP 2: Pull web loops on yoke upper and remove adjuster.



Step 3: Using adjuster, break Velcro® bond between yoke and bag.



Step 4: Adjust yoke to torso length, telescoping until seam between shoulder strap and yoke body align with top of shoulder blade.

Step 5: Replace adjuster to its original location. The adjuster doubles as a crucial piece of framing in your pack, and transfers weight through the torso and into the hips and core.